

Stainless Steel Accessories

WINDOW SHADE

INSTALLATION INSTRUCTIONS

1. Please note that this part may be secured with two sided tape only, however fastening with supplied hardware is highly recommended.
2. Insert window shade into door window ensuring that the shade follows the contour of the door window ledge and sits flush up against the rubber edging.
3. Mark holes as shown in figure below.
4. Set window shade aside and drill marked holes with 1/8" drill bit.
5. Prepare surfaces according to provided 3M tape instructions.
6. Fasten window shade with tape and supplied hardware as shown in figure below.

