


ITEM NO.	PART NO.	DESCRIPTION	QTY
1	M7231022SD	SUN VISOR PANEL	1
2	M7231022SG	SUN VISOR PANEL	1
3	K7231022BH	HARDWARE KIT INCLUDES :	1
4	-	PR9231022-D00	1
5	-	PR9231022-G00	1
6	-	PR9231004-C00	1
7	-	FLAT WASHER 1/4" SS	19
8	-	WELL NUT 1/4"-20NC	6
9	-	HEX. BOLT 1/4NC X 1	6
10	-	TRUSS PHILIPS 1/4"-20NCX3/4"SS	13
11	-	HEX NUT 1/4-20NC	13
12	-	LOCK WASHER 1/4" SS	13




TRUX ACCESSORIES

TITLE:
SUN VISOR KENWORTH
W900 & T800 GANGSTER SERIES FLAT GLASS

SIZE DWG. NO.
A **TSUN-K19**

NAME	DATE	REV	DATE
DRAWN BY P.W.	29-09-2008	PH1	-
SCALE: 1:6		WEIGHT: LBS	SHEET: 1 OF 1



FRONT

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

INSTALLATION INSTRUCTIONS

- 1- REMOVE THE EXISTING SUN VISOR.
- 2- REDRILL EXISTING HOLES TO 1/2 in. AND INSERT WELLNUTS.
- 3- INSTALL THE BRACKETS ONTO THE CAB.
- 4- TEMPORARILY INSTALL THE SUN VISOR AS ILLUSTRATED
- 5- USE RECOVERED HARDWARE FOR HOLES ON BOTH ENDS OF SUN VISOR.
- 6- IF WITHOUT LIGHTS; SKIP TO STEP#10.
- 7- INSTALL THE LIGHTS ON SUN VISOR
- 8- CONNECT THE LIGHTS AND DIRECT WIRE TOWARDS CENTER.
- 9- FASTEN THE SUN VISOR USING THE FASTENING HARDWARE.
- 10- REINSTALL THE SUN VISOR ON THE CAB.

CAUTION

IT IS THE RESPONSIBILITY OF THE INSTALLER TO PLAN AHEAD THE ADEQUATE ELECTRICAL CONNECTION ACCORDING TO THE STANDARDS OF THE TRUCK MANUFACTURER AND DOT REGISTRATION.

- 11- CONNECT LIGHTS HARNESS TO THE TRUCK.
- 12- TIGHTEN ALL BOLTS AND SCREWS FIRMLY.



BACK

TRUX ACCESSORIES			
TITLE: SUN VISOR KENWORTH W900 & T800 GANGSTER SERIES FLAT GLASS			
SIZE A	DWG. NO. TSUN-K19		
NAME	DATE	REV	DATE
DRAWN BY P.W.	29-09-2008	PH1	-
SCALE: 1:24		WEIGHT: LBS	SHEET: 1 OF 1